Measuring insert For resistance thermometer with flameproof enclosure (TR10-L) Model TR10-K

WIKA data sheet TE 60.11











for further approvals see page 2

Applications

Replacement measuring insert for servicing

Special features

- Sensor ranges from -196 ... +600 °C (-320 ... +1,112 °F)
- Made of mineral-insulated sheathed measuring cable
- For all standard thermowell designs
- Spring-loaded design
- Explosion-protected versions



Description

The measuring inserts for resistance thermometers described here are designed for installation in a thermometer model TR10-L. Operation without thermowell is appropriate only in special cases. The measuring insert is made of flexible, mineral-insulated sheathed cable. The sensor is located in the tip of the measuring insert. The measuring inserts are delivered with pressure springs to ensure that the measuring inserts are pressed down to the thermowell bottom.

The following versions are possible:

- With mounted sleeve to suit inner diameter of the thermowell
- Without terminal block
- With transmitter

Type and number of sensors, accuracy and connection method can each be selected to suit the respective application.

Measuring insert, model TR10-K

Only correct measuring insert length and correct measuring insert diameter ensure sufficient heat transfer from thermowell to the measuring insert.

The range of applications is completed by designs without terminal block for direct transmitter installation. Optionally, analogue or digital transmitters from the WIKA range can be installed.

WIKA data sheet TE 60.11 · 07/2018

Page 1 of 6



Explosion protection (option)

Attention:

The measuring insert model TR10-K is designed for use in resistance thermometer model TR10-L only.

The ignition protection type Ex d is guaranteed only if the measuring insert including the supplied threaded sleeve (flameproof joint) is built into the connection head with flameproof enclosure of the resistance thermometer model TR10-L.

Approvals (explosion protection, further approvals)

Logo	Description	Country
C€	EU declaration of conformity ■ EMC directive ¹) EN 61326 emission (group 1, class B) and immunity (industrial application)	European Union
€x>	■ RoHS directive ATEX directive (option) Hazardous areas - Ex i Zone 1 gas [II 2G Ex ia IIC T1 T6 Gb]	
IEC IECEX	IECEx (option) (in conjunction with ATEX) Hazardous areas - Ex i Zone 1 gas [Ex ia IIC T1 T6 Gb]	International
EHLEx	EAC (option) Hazardous areas - Ex i Zone 1 gas [1 Ex ib IIC T3/T4/T5/T6]	Eurasian Economic Community
IMMETRO	INMETRO (option) Hazardous areas - Ex i Zone 1 gas [Ex ib IIC T3 T6 Gb]	Brazil
Ex MEPS)	NEPSI (option) Hazardous areas - Ex i Zone 1 gas [Ex ib IIC T3 ~ T6]	China
C s	KCs - KOSHA (option) Hazardous areas - Ex i Zone 1 gas [Ex ib IIC T4 T6]	South Korea
-	PESO (option) Hazardous areas - Ex i Zone 1 gas [Ex ib IIC T3 T6 Gb]	India
©	GOST (option) Metrology, measurement technology	Russia
6	KazInMetr (option) Metrology, measurement technology	Kazakhstan
-	MTSCHS (option) Permission for commissioning	Kazakhstan
(BelGIM (option) Metrology, measurement technology	Belarus
•	UkrSEPRO (option) Metrology, measurement technology	Ukraine
	Uzstandard (option) Metrology, measurement technology	Uzbekistan

Instruments marked with "ia" may also be used in areas only requiring instruments marked with "ib" or "ic". If an instrument with "ia" marking has been used in an area with requirements in accordance with "ib" or "ic", it can no longer be operated in areas with requirements in accordance with "ia" afterwards.

Approvals and certificates, see website

Sensor

Measuring element

Pt100 (measuring current: 0.1 ... 1.0 mA) 1)


Connection method			
Single elements	1 x 2-wire 1 x 3-wire 1 x 4-wire		
Dual elements	2 x 2-wire 2 x 3-wire 2 x 4-wire ²⁾		

Accuracy class / Range of use of the sensor per EN 60751			
Class	Sensor construction		
	Wire-wound	Thin-film	
Class B	-196 +600 °C	-50 +500 °C	
Class A 3)	-100 +450 °C	-30 +300 °C	
Class AA 3)	-50 +250 °C	0 150 °C	

¹⁾ For detailed specifications for Pt100 sensors, see Technical information IN 00.17 at www.wika.de.

The table shows the temperature ranges listed in the respective standards, in which the tolerance values (class accuracies) are valid.

Electrical connection (colour code per IEC/EN 60751)



For the electrical connections of built-in temperature transmitters see the corresponding data sheets or operating instructions.

²⁾ Not with 3 mm diameter3) Not with 2-wire connection method

Transmitter (option)

A transmitter can be built upon the measuring insert. In this case, the transmitter replaces the terminal block and is directly attached to the terminal plate of the measuring insert.











Output signal 4 20 mA, HART® protocol, FOUNDATION™ Fieldbus and PROFIBUS® PA				
Transmitter (selectable versions)	Model T15	Model T32	Model T53	Model T91.10
Data sheet	TE 15.01	TE 32.04	TE 53.01	TE 91.01
Output				
■ 420 mA	Х	х		х
■ HART® protocol		х		
■ FOUNDATION™ Fieldbus and PROFIBUS® PA			х	
Connection method				
■ 1 x 2-wire, 3-wire or 4-wire	Х	х	Х	х
Measuring current	< 0.2 mA	< 0.3 mA	< 0.2 mA	0.8 1 mA
Explosion protection	Optional	Optional	Standard	-



Measuring insert with mounted transmitter (here: Model T32)



Measuring insert prepared for transmitter mounting

Functional safety (option) with temperature transmitter model T32




In safety-critical applications, the entire measuring chain must be taken into consideration in terms of the safety parameters. The SIL classification allows the assessment of the risk reduction achieved by the safety installations.

Selected TR10-K measuring inserts in combination with a suitable temperature transmitter (e.g. model T32.1S, TÜV certified SIL version for protection systems developed in accordance with IEC 61508) are suitable as sensors for safety functions to SIL 2.

Suitable thermowells allow easy dismounting of the measuring insert for calibration. The optimally matched measuring point consists of a thermowell, a thermometer with built-in TR10-K measuring insert and a T32.1S transmitter developed in accordance with IEC 61508. Thus, the measuring point provides maximum reliability and a long service life.

Dimensions in mm



Measuring insert length I ₅ in mm	Tolerance in mm
75 825	+2
> 825	+3 0

Please note:

Max. measuring insert length = 1,100 mm

Only on explicit request do we deliver measuring inserts with lengths of greater than 1,100 mm in a stretched, straight form.

To specify this in the order, please contact your WIKA contact person.

Measuring insert diar Ø d in mm	meter	Index per DIN 43735	Tolerance in mm
3 ¹⁾	Standard	30	3 ±0.05
6	Standard	60	6 -0.1
8 (6 mm with sleeve)	Standard	-	8 -0.1
8	Standard	80	8 -0.1
1/8 inch (3.17 mm) ¹⁾ 1/4 inch (6.35 mm) 3/8 inch (9.53 mm)	Option, on request	-	-

¹⁾ Not possible with 2 x Pt100, 4-wire

Measuring insert

The measuring insert is made of a vibration-resistant, sheathed measuring cable (MI cable).

The measuring insert diameter should be approx. 1 mm smaller than the bore diameter of the thermowell. Gaps of more than 0.5 mm between thermowell and the measuring insert will have a negative effect on the heat transfer, and they will result in unfavourable response behaviour of the thermometer.

Using two screws and springs, the measuring insert can be mounted into a connection head (with flameproof enclosure, models 1/4000, 7/8000), replaceable and mounted springloaded.

When fitting the measuring insert into a thermowell, it is very important to determine the correct insertion length (= thermowell length for bottom thicknesses of \leq 5.5 mm). In order to ensure that the measuring insert is firmly pressed down onto the bottom of the thermowell, the insert must be spring-loaded (spring travel: max 10 mm).

The standard material used for the measuring insert sheath is stainless steel. Other materials on request.

Besides twistability, this series is characterised by a high vibration resistance of the probe tip (6 g peak-to-peak 1).

1) In combination with TR10-L, vibration resistance data of the TR10-L apply.

Attention:

Operation of the model TR10-K measuring instrument is not permitted in hazardous areas without flame path and connection head with flameproof enclosure!

Flame path

A flame path is built into the connection head which, in conjunction with the measuring insert, generates a flameproof joint.

If servicing is required, we recommend replacing the flame path together with the measuring insert.



Fig. left: Flame path for model 1/4000 connection head (order number: 14064383)

Fig. right: Flame path for model 7/8000 connection head and 7/8000 with DIH50 (order number 3265731)

Certificates (option)

Certification type	Measurement accuracy	Material certificate
2.2 test report	X	х
3.1 inspection certificate	X	х
DKD/DAkkS calibration certificate	х	-

The different certifications can be combined with each other.

Ordering information

WIKA data sheet TE 60.11 · 07/2018

Model / Explosion protection / Measuring insert design / Terminal block, transmitter / Measuring element / Sensor connection method / Connection head / Temperature range / Probe tip design / Probe diameter / Sheath, tube material / Measuring insert length / Certificates / Options

© 03/2013 WIKA Alexander Wiegand SE & Co. KG, all rights reserved. The specifications given in this document represent the state of engineering at the time of publishing We reserve the right to make modifications to the specifications and materials.

Page 6 of 6

63911 Klingenberg/Germany +49 9372 132-0

info@wika.de www.wika.de